



- 02. 앞무대조명 (APRON LIGHT)
- 01. 현수막봉 (PLACARD BATTEN)
- 01. 영사막 (SCREEN)
- 00. 영평선 (ZERO LINE)
- 02. 모양막 (CONTOUR CURTAIN)
- 03. 광막 1 (#1 DRAW CURTAIN)
- 04. 보더라이프 1 + 마리아막 1 (#1 BORDER LIGHT + #1 HOUSE BORDER)
- 05. 조광봉 1 (#1 LIGHT BATTEN)
- 06. 천장음향반사판 1 (#1 ACOUSTICAL SHELL-CEILING)
- 07,08. 측면음향반사판 1.3 (#1.3 ACOUSTICAL SHELL-SIDE WALL)
- 09. 장치봉 1 (#1 SET BATTEN)
- 10. 광막 2 (#2 DRAW CURTAIN)
- 11. 장치봉 2 (#2 SET BATTEN)
- 12. 장치봉 3 (#3 SET BATTEN)
- 13. 보더라이프 2 + 마리아막 2 (#2 BORDER LIGHT + #2 HOUSE BORDER)
- 14. 조광봉 2 (#2 LIGHT BATTEN)
- 15. 광막 3 (#3 DRAW CURTAIN)
- 16. 천장음향반사판 2 (#2 ACOUSTICAL SHELL-CEILING)
- 17,18. 측면음향반사판 2.4 (#2.4 ACOUSTICAL SHELL-SIDE WALL)
- 19. 장치봉 4 (#4 SET BATTEN)
- 20. 장치봉 5 (#5 SET BATTEN)
- 21. 광막 4 (#4 DRAW CURTAIN)
- 22. 장치봉 6 (#6 SET BATTEN)
- 23. 후면음향반사판 (ACOUSTICAL SHELL-BACK WALL)
- 24. 보더라이프 3 + 마리아막 3 (#3 BORDER LIGHT + #3 HOUSE BORDER)
- 25. 조광봉 3 (#3 LIGHT BATTEN)
- 26. 광막 5 (#5 DRAW CURTAIN)
- 27. 하늘막상단조명 + 마리아막 4 (SKY CYC. LIGHT + #4 HOUSE BORDER)
- 28. 장치봉 7 (#7 SET BATTEN)
- 29. 장치봉 8 (#8 SET BATTEN)
- 30. 하늘막 (CYCLORAMA)